


# Narrow Crown Stapler



**For replacement parts or technical assistance, call 1-888-241-5858**

Please provide following information:

- Model number
- Serial number (if any)
- Part description and number as shown in parts list

Address parts correspondence to:

Attn: Parts Department  
 100 Production Drive  
 Harrison, OH 45030 U.S.A.

| Ref. No. | Description                | Part Number | Qty. |
|----------|----------------------------|-------------|------|
| 1        | Exhaust deflector          | SV490000AV  | 1    |
| 2        | Hex. socket head bolt      | SV490100AV  | 4    |
| 3        | Spring washer              | SV490200AV  | 6    |
| 4        | Head cap                   | SV490300AV  | 1    |
| 5        | Seal washer                | *           | 1    |
| 6        | O-ring                     | *           | 1    |
| 7        | Internal lining            | SV490600AV  | 1    |
| 8        | O-ring                     | ● *         | 1    |
| 9        | Compression spring         | ●           | 1    |
| 10       | Balance valve              | ●           | 1    |
| 11       | O-ring                     | ● *         | 1    |
| 12       | O-ring                     | ● *         | 1    |
| 13       | O-ring                     | ● *         | 1    |
| 14       | O-ring                     | ■ *         | 1    |
| 15       | Ring                       | ■ *         | 1    |
| 16       | Piston                     | ■           | 1    |
| 17       | Driver Blade               | ■           | 1    |
| 18       | Collar                     | SV491600AV  | 1    |
| 19       | O-ring                     | *           | 1    |
| 20       | O-ring                     | *           | 1    |
| 21       | Cylinder                   | SV491900AV  | 1    |
| 22       | Bumper                     | SV492000AV  | 1    |
| 23       | Gasket                     | *           | 1    |
| 24       | Nozzle shield              | SV489700AV  | 1    |
| 25       | Body                       | SV489600AV  | 1    |
| 26       | Nozzle                     | SV492600AV  | 1    |
| 27       | Driver guide               | SV499300AV  | 1    |
| 28       | Hex. socket head bolt      | SV492800AV  | 2    |
| 29       | Spacer                     | SV492900AV  | 1    |
| 30       | Hex. socket head bolt      | SV493000AV  | 2    |
| 31       | Upper driver guide         | SV499400AV  | 1    |
| 32       | Driver guide cover         | SV493200AV  | 1    |
| 33       | Pin                        | SV493300AV  | 2    |
| 34       | Pin                        | SV493400AV  | 1    |
| 35       | O-ring                     | SV493500AV  | 1    |
| 36       | Depth control guide frame  | SV493600AV  | 1    |
| 37       | Safety spring              | SV493700AV  | 1    |
| 38       | Depth control guide body   | SV493800AV  | 1    |
| 39       | Steel ball                 | SV493900AV  | 2    |
| 40       | Spring                     | SV494000AV  | 2    |
| 41       | Thumbwheel                 | SV494100AV  | 1    |
| 42       | Upper work contact element | SV494200AV  | 1    |
| 43       | Lower work contact element | SV494300AV  | 1    |
| 44       | No-mar tip                 | SV494400AV  | 1    |
| 45       | Spring washer              | SV494500AV  | 3    |
| 46       | Hex. socket head bolt      | SV494600AV  | 1    |
| 47       | Inner seal                 | ▲ *         | 1    |
| 48       | Upper valve body           | SV494800AV  | 1    |
| 49       | Inner trigger spring       | SV494900AV  | 1    |
| 50       | O-ring                     | ▲ *         | 2    |

| Ref. No. | Description           | Part Number | Qty. |
|----------|-----------------------|-------------|------|
| 51       | Trigger valve plunger | SV495100AV  | 1    |
| 52       | O-ring                | ▲ *         | 1    |
| 53       | Lower valve body      | SV495300AV  | 1    |
| 54       | Trigger spring        | □           | 1    |
| 55       | Trigger plate         | □           | 1    |
| 56       | Spring pin            | □           | 1    |
| 57       | Trigger               | □           | 1    |
| 58       | Pin for trigger       | □           | 1    |
| 59       | O-ring                | □ * ▲       | 1    |
| 60       | Bushing               | SV496000AV  | 1    |
| 61       | Torsion spring        | SV496100AV  | 1    |
| 62       | Quick release latch   | SV496200AV  | 1    |
| 63       | Hex. socket head bolt | SV496300AV  | 1    |
| 64       | Button cover          | SV496400AV  | 1    |
| 65       | Magazine B            | SV499500AV  | 1    |
| 66       | Pusher                | ◆           | 1    |
| 67       | Spring holder         | ◆           | 2    |
| 68       | Pusher spring         | ◆           | 2    |
| 69       | Magazine A            | SV496900AV  | 1    |
| 70       | Spring washer         | SV497000AV  | 1    |
| 71       | Hex. socket head bolt | SV497100AV  | 1    |
| 72       | Flat head screw       | SV497200AV  | 1    |
| 73       | Magazine end stop     | SV497300AV  | 1    |
| 74       | Magazine pad          | SV497400AV  | 1    |
| 75       | Spring pin            | SV497500AV  | 1    |
| 76       | Spring                | SV497600AV  | 1    |
| 77       | Magazine latch button | SV497700AV  | 1    |
| 78       | Spring pin            | SV497800AV  | 1    |
| 79       | Tail hanger           | SV497900AV  | 1    |
| 80       | Hex. socket head bolt | SV498000AV  | 2    |
| 81       | Hand grip             | SV498200AV  | 1    |
| 82       | O-ring                | *           | 1    |
| 83       | End cap               | SV489800AV  | 1    |

**REPLACEMENT PARTS KITS**

|   |                                 |            |
|---|---------------------------------|------------|
| ◆ | Pusher assembly                 | SKN00900AV |
| ▲ | Trigger valve o-ring kit        | SKN01000AV |
| ■ | Driver kit                      | SKN01600AV |
| ● | Balance valve assembly          | SKN01200AV |
| □ | Trigger assembly                | SKN01300AV |
| * | Complete o-ring replacement kit | SKN01700AV |