


Replacement Parts List

Models PW134500AV, PW134501AV, PW134599AV, PW135000LE,
PW136500AV, PW137500AV, PW137501AV, PW137599AV, & PW138000AV



For Replacement Parts, Call 1-800-237-0987

Please provide following information:

- Model number
- Serial number (if any)
- Part description and number as shown in parts list

Address parts correspondence to:

Campbell Group/Parts Department
100 Production Drive
Harrison, OH 45030

Ref. No.	Description	Part No.	Qty.	Ref. No.	Description	Part No.	Qty.
1	On/off switch	PM041900SV	1	12	Bolt, head (includes 1 bolt)	PM025100SV	1
* 2	Motor assembly, universal			13	Inlet valve kit (includes 3 valves & 3 o-rings)	PM064740SV	1
	PW1345XXAV	PM222500SJ	1	14	Seal, water (includes 3 seals)	PM064730SV	1
	PW1350000LE	PM222500SJ	1	15	Piston guide kit	PM064720SV	1
	PW136500AV	PM222600SJ	1	16	Seal, oil (includes 3 seals)	PM064710SV	1
	PW1375XXAV	PM222500SJ	1	17	Filter, suction	PM014800SV	1
	PW138000AV	PM222700SJ	1	18	Internal chemical injector	PM062300SV	1
3	Power cord, 16 AWG, 2 wire	PM060100SV	1	19	Unloader kit, (includes cap, o-ring and unloader assembly)	PM080621SV	1
4	Needle bearing kit	PM041840SV	1	20	Microswitch assembly for instant start/stop system	PM080619SV	1
5	Piston kit (includes 3 pistons and springs)	PM058200SV	1	21	Detergent injector kit (includes barb, spring, ball, and o-ring)	PM064305SV	1
6	O-ring, 85X2.5	PM057800SV	1	22	Unloader cap with o-ring	PM057300SV	1
7	Piston body	PM040600SV	1	23	Unloader spring	PM057500SV	1
8	O-ring, high pressure, head	PM041870SV	1	24	Unloader housing & poppet	PM057400SV	1
9	Kit, valve cap (includes 3 caps)	PM064750SV	1				
10	Valve, outlet (includes 3 valves/o-rings)	PM064304SV	1				
11	Head, manifold	PM025200SV	1				

* Unit assembly maybe shipped if replacement motor is not available.