

# For Replacement Parts, call 1-888-241-5858

Please provide following information:  
 - Model number  
 - Serial number (if any)  
 - Part description and number as shown in parts list.

Address parts correspondence to:  
 Campbell Hausfeld  
 Attn: Parts Department  
 100 Production Drive  
 Harrison, OH 45030 U.S.A.

Ref. No.	Description	Part Number	Qty.
----------	-------------	-------------	------

1	Exhaust deflector	SV451000AV	1
2	Hex. socket head bolt	SV451100AV	4
3	Spring washer	SV451200AV	4
4	Head cap	SV451300AV	1
5	Seal washer	SV451400AV	1
6	O-ring	SV451600AV	1
7	Internal lining	SV451800AV	1
8	O-ring	SV451800AV	1
9	Compression spring	SV451800AV	1
10	Balance valve	SV451800AV	1
11	O-ring	SV451800AV	1
12	O-ring	SV451800AV	1
13	O-ring	SV451800AV	1
14	O-ring	SV451800AV	1
15	Ring	SV451800AV	1
16	Driver assembly	SV452700AV	1
17	Lining ring	SV452700AV	1
18	O-ring	SV452700AV	1
19	O-ring	SV452700AV	1
20	Cylinder	SV453000AV	1
21	O-ring	SV453200AV	1
22	Bumper	SV453300AV	1
23	Gasket	SV453300AV	1
24	Body with grip	SV472500AV	1
25	Nozzle	SV453500AV	1
26	Inner seal	SV453700AV	1
27	Upper valve body	SV453800AV	1
28	Inner trigger spring	SV453800AV	1
29	O-ring	SV454000AV	2
30	Trigger valve plunger	SV454000AV	1
31	Lower valve body	SV454100AV	1
32	O-ring	SV454100AV	1
33	Trigger spring	SV454300AV	1
34	Trigger assembly	SV454300AV	1
35	Pin	SV454800AV	2
36	O-ring	SV454800AV	2
37	Depth control guide frame	SV443600AV	1
38	Safety spring	SV455000AV	1
39	Depth control guide body	SV455100AV	1
40	Depth adjusting assembly	SV443500AV	1
41	Work contact element	SV455700AV	1
42	No-mar tip	SV455800AV	1
43	Side shield	SV455900AV	1
44	Flat head screw	SV456000AV	2
45	Twist spring	SV456100AV	1

Ref. No.	Description	Part Number	Qty.
----------	-------------	-------------	------

46	Spring alignment bushing	SV456200AV	1
47	Quick release button	SV456300AV	1
48	Button cover	SV456400AV	1
49	Latch washer	SV456500AV	1
50	Hex. socket head bolt	SV456600AV	2
51	O-ring	SV456800AV	1
52	End cap	SV471300AV	1
53	Hex. socket head bolt	SV457000AV	1
54	End hollow cover	SV457100AV	1
55	Nozzle shield	SV471400AV	1
56	Hex. socket head bolt	SV457500AV	2
57	Spacer	SV457600AV	1
58	Driver guide cover	SV457700AV	1
59	Hex. socket head bolt	SV457800AV	1
60	Hex. socket head bolt	SV457900AV	1
61	Driver guide	SV458000AV	1
62	Steel bar	SV458100AV	1
63	Outer magazine	SV458200AV	1
64	Push unit	SV458200AV	1
65	Spring holding	SV458200AV	2
66	Magazine spring	SV458600AV	2
67	Spring pin	SV458700AV	1
68	Inner magazine	SV458700AV	1
69	Hex. socket head bolt	SV458800AV	1
70	Click lever	SV458900AV	1
71	Twist spring	SV459000AV	1
72	Hex. socket head bolt	SV459100AV	1
73	Magazine latch button	SV459200AV	1
74	Magazine end stop	SV459300AV	1
75	Magazine pad	SV459400AV	1
76*	4 mm Hex wrench	SV109400AV	1
77*	3 mm Hex wrench	SV109300AV	1
78*	Oil daily decal	DK581400AV	1
79*	Warning decal	DK584900AV	1
80*	Name decal	DK584800AV	1

### REPLACEMENT PARTS KITS

▲	Pusher assembly	SV460400AV
■	Trigger o-ring kit	SV460500AV
●	Driver kit	SV460600AV
◆	Balance valve assembly	SV460700AV
▼	Trigger assembly	SV460800AV
□	Complete o-ring replacement kit	SV460900AV

\* Not shown



# Brad Nailer

Replacement Parts Manual

MXN10299AV

