




Portable Air Compressors Compresseurs D'Air Portatifs Compresores De Aire Portatiles

Replacement Parts List
Liste De Pièces De Rechange
Lista De Repuestos

WL502403, WL503501, WL503600, WL503700, WL5038, WL600607,
WL600707, WL602102, WL602303, WL604002, WL604102, WL604701,
WL604802, WL605202, WL605301, WL610002



NOTE: Model WL5036 (pump only) includes Ref. Nos. 1 & 24 thru 27 listed under Model WL5035 on page 2.

Model WL5037 (pump only) includes Ref. Nos. 1 & 24 thru 27 listed under Model WL5038 on page 2.

REMARQUE: Le Modèle WL5036 (pompe seulement) comprend les N° de Réf. 1 & 24 à 27 énumérés sous le Modèle WL5035 sur la page 2.

Le Modèle WL5037 (pompe seulement) comprend les N° de Réf. 1 & 24 à 27 énumérés sous le Modèle WL5038 sur la page 2

NOTA: El modelo WL5036 (Sólo el cabezal) incluye los Nos. de Ref. 1 & 24 al 27 enumerados bajo el modelo WL5035 en la página 2.

El modelo WL5036 (Sólo el cabezal) incluye los Nos. de Ref. 1 & 24 al 27 enumerados bajo el modelo WL5038 en la página 2.

For Replacement Parts, Call 1-800-543-6400

Please provide following information:

- Model number
- Serial number (if any)
- Part description and number as shown in parts list

Address parts correspondence to:

The Campbell Group/Attn: Parts Dept.
100 Production Drive
Harrison, OH 45030 U.S.A.

Ref. No.	Description	Part Number for Models:					Qty.
		WL502403	WL503501	WL503805	WL600607	WL600707	
1	† Pump/motor	WL301104AJ	WL301502AJ	WL302502AJ	WL340003AJ	WL340003AJ	1
2	Compression Ferrule	ST032900AV	ST032900AV	ST032900AV	ST032900AV	ST032900AV	1
3	Compression nut	ST033001AV	ST033001AV	ST033001AV	ST033001AV	ST033001AV	2
4	Exhaust tube	WL004000AP*	WL004900AP	WL004900AP	WL001901AP	WL001901AP	1
5	Rubber ferrule	ST067300AV	ST067300AV	ST067300AV	ST067300AV	ST067300AV	1
6	Check valve	CV221500AJ	CV221500AJ	CV221500AJ	CV221500AJ	CV221500AJ	1
7	Isolation Mount	—	—	—	WL003201AV	WL003201AV	2
8	Drain cock	D-1401	D-1401	D-1401	D-1401	D-1401	1
9	Foot	ST162600AV	ST162600AV	ST162600AV	ST041600AV	ST041600AV	2
10	Tank	AR043700JY	AR043700JY	AR043700JY	AR043500JY	AR025802JY	1
11	Mounting Bolt	ST116400AV	ST116400AV	ST116400AV	ST158000AV	ST158000AV	3
12	Shroud tapping screw	ST129302AV	ST129302AV	ST129302AV	ST129302AV	ST129302AV	2
13	Unloader tube	ST079702AV	ST079702AV	ST079702AV	ST079702AV	ST079702AV	1
14	Hex Head Lock Nut	ST033500AV	ST033500AV	ST033500AV	ST033500AV	ST033500AV	2
15	■ 1/4-18 Nipple	HF002401AV	HF002401AV	HF002401AV	HF002401AV	HF002401AV	2
16	■ Regulator	RE206203AV	RE206203AV	RE206203AV	RE206203AV	RE206203AV	1
17	● Gauge	GA016300AV	GA016300AV	GA016300AV	GA016300AV	GA016300AV	2
18	● Reducer 1/8-27 x 1/4-18	ST071407AV	ST071407AV	ST071407AV	ST071407AV	ST071407AV	1
19	● Pressure Switch	CW207576AV	CW207576AV	CW207576AV	CW207576AV	CW207576AV	1
20	● Unloader Valve	CW000800AV	CW000800AV	CW000800AV	CW000800AV	CW000800AV	1
21	Strain Relief	CW000702AV	CW000702AV	CW000702AV	CW000702AV	CW000702AV	1
22	● Safety Valve	V-215100AV	V-215100AV	V-215100AV	V-215100AV	V-215100AV	1
23	Power Cord & Plug	EC012601AV	EC012601AV	EC012601AV	EC012601AV	EC012601AV	1
24	Shroud	WL001501AV	WL001501AV	WL001501AV	WL001501AV	WL001501AV	1
25	Rear cover	WL002202AV	WL002202AV	WL002202AV	WL002202AV	WL002202AV	1
26	M2 x 12mm Plascrew	ST158400AV	ST158400AV	ST158400AV	ST158400AV	ST158400AV	1
27	M4 x 13mm Shroud Screw	ST129301AV	ST129301AV	ST129301AV	ST129301AV	ST129301AV	2
28	Strain Relief Screw	ST074418AV	ST074418AV	ST074418AV	ST074418AV	ST074418AV	1
29	Isolation Mount	—	—	—	WL003202AV	WL003202AV	1
30	Handle	HL001800BH	HL001800BH	HL001800BH	HL001800BH	HL001800BH	1
31	1/4-20 Handle Screw	ST073236AV	ST073236AV	ST073236AV	ST073236AV	ST073236AV	2
32	Wheel	WA002400AV	WA002400AV	WA002400AV	WA002400AV	WA002400AV	2
33	Hex Head Axle Bolt	ST033400AV	ST033400AV	ST033400AV	ST033400AV	ST033400AV	2
34	Warning Decal, 3 piece	DK630000AV	DK630000AV	DK630000AV	DK630000AV	DK630000AV	1
35	Stop Nut	ST146000AV	ST146000AV	ST146000AV	—	—	2
■	Regulator assembly	CV302900AJ	CV302900AJ	CV302900AJ	CV302900AJ	CV302900AJ	1
●	Pressure switch assembly	CV303100AJ	CV303100AJ	CV303100AJ	CV303100AJ	CV303100AJ	1

† Items 24-27 are not included with the pump/motor

* Model WL5024 Exhaust tube uses ST072214AV elbow fitting

For Replacement Parts, Call 1-800-543-6400

Please provide following information:

- Model number
- Serial number (if any)
- Part description and number as shown in parts list

Address parts correspondence to:

The Campbell Group/Attn: Parts Dept.
100 Production Drive
Harrison, OH 45030 U.S.A.

Ref. No.	Description	WL602102		WL604003		WL610002	WL605202	Qty.
		WL605301	WL602303	WL604701	WL604801			
1 †	Pump/motor	WL340003AJ	WL340003AJ	WL340003AJ	WL340003AJ	WL350002AJ	WL350002AJ	1
2	Compression Ferrule	ST032900AV	ST032900AV	ST032900AV	ST032900AV	ST032900AV	ST032900AV	1
3	Compression nut	ST033001AV	ST033001AV	ST033001AV	ST033001AV	ST033001AV	ST033001AV	2
4	Exhaust tube	WL001901AP	WL001901AP	WL001901AP	WL001901AP	WL001901AP	WL001901AP	1
5	Rubber ferrule	ST067300AV	ST067300AV	ST067300AV	ST067300AV	ST067300AV	ST067300AV	1
6	Check valve	CV221500AJ	CV221500AJ	CV221500AJ	CV221500AJ	CV221500AJ	CV221500AJ	1
7	Isolation Mount	WL003201AV	WL003201AV	WL003201AV	WL003201AV	WL003201AV	WL003201AV	2
8	Drain cock	D-1401	D-1401	D-1401	D-1401	D-1401	D-1401	1
9	Foot	ST041600AV	ST041600AV	ST041600AV	ST041600AV	ST041600AV	ST041600AV	2
10	Tank	AR025802JY	AR026900JY	AR043200JY	AR043200JY	AR025802JY	AR026900JY	1
11	Mounting Bolt	ST158000AV	ST158000AV	ST158000AV	ST158000AV	ST158000AV	ST158000AV	3
12	Shroud tapping screw	ST129302AV	ST129302AV	ST129302AV	ST129302AV	ST129302AV	ST129302AV	2
13	Unloader tube	ST079702AV	ST079702AV	ST079702AV	ST079702AV	ST079702AV	ST079702AV	1
14	Hex Head Lock Nut	ST033500AV	ST033500AV	ST033500AV	ST033500AV	ST033500AV	ST033500AV	2
15 ■	1/4-18 Nipple	HF002401AV	HF002401AV	HF002401AV	HF002401AV	HF002401AV	HF002401AV	2
16 ■	Regulator	RE206203AV	RE206203AV	RE206203AV	RE206203AV	RE206203AV	RE206203AV	1
17 ●	Gauge	GA016300AV	GA016300AV	GA016300AV	GA016300AV	GA016300AV	GA016300AV	2
18 ●	Reducer 1/8-27 x 1/4-18	ST071407AV	ST071407AV	ST071407AV	ST071407AV	ST071407AV	ST071407AV	1
19 ●	Pressure Switch	CW207576AV	CW207576AV	CW207576AV	CW207576AV	CW207576AV	CW207576AV	1
20 ●	Unloader Valve	CW000800AV	CW000800AV	CW000800AV	CW000800AV	CW000800AV	CW000800AV	1
21	Strain Relief	CW000702AV	CW000702AV	CW000702AV	CW000702AV	CW000702AV	CW000702AV	1
22 ●	Safety Valve	V-215100AV	V-215100AV	V-215100AV	V-215100AV	V-215100AV	V-215100AV	1
23	Power Cord & Plug	EC012601AV	EC012601AV	EC012601AV	EC012601AV	EC012601AV	EC012601AV	1
24	Shroud	WL001501AV	WL001501AV	WL001501AV	WL001501AV	WL001501AV	WL001501AV	1
25	Rear cover	WL002202AV	WL002202AV	WL002202AV	WL002202AV	WL002202AV	WL002202AV	1
26	M2 x 12mm Plascrew	ST158400AV	ST158400AV	ST158400AV	ST158400AV	ST158400AV	ST158400AV	1
27	M4 x 13mm Shroud Screw	ST129301AV	ST129301AV	ST129301AV	ST129301AV	ST129301AV	ST129301AV	2
28	Strain Relief Screw	ST074418AV	ST074418AV	ST074418AV	ST074418AV	ST074418AV	ST074418AV	1
29	Isolation Mount	WL003202AV	WL003202AV	WL003202AV	WL003202AV	WL003202AV	WL003202AV	1
30	Handle	HL001800BH	HL001800BH	HL001800BH	HL001800BH	HL001800BH	HL001800BH	1
31	1/4-20 Handle Screw	ST073236AV	ST073236AV	ST073236AV	ST073236AV	ST073236AV	ST073236AV	2
32	Wheel	WA002400AV	WA002400AV	WA002400AV	WA002400AV	WA002400AV	WA002400AV	2
33	Hex Head Axle Bolt	ST033400AV	ST033400AV	ST033400AV	ST033400AV	ST033400AV	ST033400AV	2
34	Warning Decal, 3 piece	DK630000AV	DK630000AV	DK630000AV	DK630000AV	DK630000AV	DK630000AV	1
■	Regulator assembly	CV302900AJ	CV302900AJ	CV302900AJ	CV302900AJ	CV302900AJ	CV302900AJ	1
●	Pressure switch assembly	CV303100AJ	CV303100AJ	CV303100AJ	CV303100AJ	CV303100AJ	CV303100AJ	1

† Items 24-27 are not included with the pump/motor

* Model WL5024 Exhaust tube uses ST072214AV elbow fitting