


Oilless Air Compressors

Compresseurs d'Air Sans Huile

Compressores Sin Aceite

Replacement Parts List
 Lista de Repuestos
 Liste de Pièces de Rechange

WL660004, WL660102, WL660302,
 WL660402, WL611106, WL660700



Replacement Parts List

For Replacement Parts, Call 1-800-543-6400

Address parts correspondence to:

Please provide the following information:

- Model number
- Serial number (if any)
- Part description and number as shown in parts list

Attn: Parts Dept.
100 Production Drive
Harrison, OH 45030 USA

Ref. No.	Description	Part Number					Qty.
		WL660004	WL660102	WL611106	WL660302 WL660402	WL660700	
1	Top cover	WL016900AV	WL016900AV	WL016900AV	WL016900AV	WL016901AV	1
2	Lower cover	WL008501AV	WL008501AV	WL008501AV	WL008501AV	WL008502AV	1
3	Screw	ST058502AV	ST058502AV	ST058502AV	ST058502AV	ST058502AV	2
4	1/4" - 20 x 3/4" Screw	ST074415AV	ST074415AV	ST074415AV	ST074415AV	ST074415AV	4
5	Motor bracket	BA018300AV	BA018300AV	BA018300AV	BA018300AV	BA018300AV	1
6	■ Pump/motor assembly	WL390100AJ	WL390100AJ	WL390100AJ	WL390100AJ	WL390100AJ	1
7	Compression nut	ST033001AV	ST033001AV	ST033001AV	ST033001AV	ST033001AV	2
8	Rubber sleeve	ST085200AV	ST085200AV	ST085200AV	ST085200AV	ST085200AV	2
9	Exhaust tube	WL021800AP	WL021800AP	WL021800AP	WL021800AP	WL021800AP	1
10	Check valve	CV222201AJ	CV222201AJ	CV222201AJ	CV222201AJ	CV222201AJ	1
11	▲ Motor pad	WL007802AV	WL007802AV	WL007802AV	WL007802AV	WL007802AV	1
12	▲ Grommet	WL008000AV	WL008000AV	WL008000AV	WL008000AV	WL008000AV	1
13	Tank	AR045200CG	AR045200CG	AR045600CG	AR045700CG	AR045700CG	1
14	Wheel	WA004000AV	WA004000AV	WA004000AV	WA004000AV	WA004000AV	2
15	Axle bolt	ST033400AV	ST033400AV	ST033400AV	ST033400AV	ST033400AV	2
16	Nut	ST033500AV	ST033500AV	ST033500AV	ST033500AV	ST033500AV	2
17	Foot	ST158300AV	ST158300AV	ST158300AV	ST158300AV	ST158300AV	2
18	5/16" - 18 x 3/4" Screw	ST016000AV	ST016000AV	ST016000AV	ST016000AV	ST016000AV	2
19	Nut	ST146001AV	ST146001AV	ST146001AV	ST146001AV	ST146001AV	2
20	Pressure switch	CW209400AV	CW209400AV	CW209400AV	CW209400AV	CW211400AV	1
21	Safety valve	V-215105AV	V-215105AV	V-215105AV	V-215105AV	V-215106AV	1
22	Gauge	GA016303AV	GA016303AV	GA016303AV	GA016303AV	GA016306AV	2
23	Regulator	RE300000AJ	RE300000AJ	RE300000AJ	RE300000AJ	RE300000AJ	1
24	Nipple	HF007301AV	—	—	—	—	2
	Nipple	—	HF007301AV	HF007301AV	HF007301AV	HF007301AV	1
25	Drain cock	D-1403	D-1403	D-1403	D-1403	D-1403	1
26	Power cord with plug	EC012601AV	EC012601AV	EC012601AV	EC012601AV	EC012601AV	1
27	Clip	WL012700AV	WL012700AV	WL012700AV	WL012700AV	WL012700AV	1
28	Flexible tube	ST117803AV	ST117803AV	ST117803AV	ST117803AV	ST117803AV	1
29	Inlet tube	WL011801AV	WL011801AV	WL011801AV	WL011801AV	WL011801AV	1
30	1/4" - 20 x 1 1/4" Screw	ST073273AV	ST073273AV	ST073273AV	ST073273AV	ST073273AV	2
31	Pipe nipple	ST070350AV	ST070350AV	ST070350AV	ST070350AV	ST070350AV	1
32	Coupler	MP288300AV	—	—	—	—	1
33	Washer	ST070933AV	ST070933AV	ST070933AV	ST070933AV	ST070933AV	1
34	Handle Grip	WL012100AV	—	—	—	—	1
35	Handle	HL004700AV	HL004700AV	HL004700AV	HL004700AV	HL004700AV	1
36	1/4" - 20 x 7/8" Screw	ST073236AV	ST073236AV	ST073236AV	ST073236AV	ST073236AV	2
37	1/4" - 20 x 3/4" Screw	ST120200AV	ST120200AV	ST120200AV	ST120200AV	ST120200AV	1
38	Washer	ST070910AV	ST070910AV	ST070910AV	ST070910AV	ST070910AV	1

REPLACEMENT PARTS KITS

▲	Isolator kit (Includes #11, 12, 13)	WL211300AJ	WL211300AJ	WL211300AJ	WL211300AJ	WL211300AJ	1
■	Motor kit (includes #11)	WL212000AJ	WL212000AJ	WL212000AJ	WL212000AJ	WL212000AJ	1